

INSTRUCTION AND INSTALLATION SHEET

FOR ICE BARRIER KIT

(PN 82-3097, 82-3194, AND 82-3195)

1. INSTALLATION PROCEDURE


1. Turn OFF the Unit's power.
2. Remove the Cup Rest, Splash Plate and Drip Tray.
3. Install Ice Barrier (PN 30-7337, 23 x 23 IC; PN 30-8641, 30 x 23 IC; or, PN 30-8642, 15 x 23 IC).

Note:

Ensure that right front tab is inserted into tower clearance hole and that the two clips are sitting on the rim (see Figure 1). *This note does not apply to 15 x 23 IC units.*

4. Re-install Drip Tray, Splash Plate and Cup Rest.
5. Restore power to unit.

Please refer to the Lancer web site (www.lancercorp.com) for information relating to Lancer Installation and Service Manuals, Instruction Sheets, Technical Bulletins, Service Bulletins, etc.



Ice Barrier Installation
Figure 1

LANCER

6655 LANCER BLVD. • SAN ANTONIO, TEXAS 78219 USA • (210) 310-7000

FAX SALES

• NORTH AMERICA – 210-310-7245 • INTERNATIONAL SALES – 210-310-7242 • CUSTOMER SERVICE – 210-310-7242 •
• LATIN AMERICA – 210-310-7245 • EUROPE – 32-2-755-2399 • PACIFIC – 61-8-8268-1978 •

FAX ENGINEERING: • 210-310-7096

"Lancer" is the registered trademark of Lancer • Copyright — 2001 by Lancer, all rights reserved.

DATE: 11/02/01
P.N.: 28-0488/01